


BONGO INSTALLATION INSTRUCTIONS



WARNING - RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY. FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL SPECIFICATIONS. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING. **RETAIN THESE INSTRUCTIONS FOR MAINTENANCE REFERENCE.**

**USE THE MOUNTING DISC TO
MAKE A HOLE WITH A SIMILAR
DIAMETER TO THE MIDDLE
OPENING ON THE DISC.**



NOTE: ROUND FRAME INSTALLATION SHOWN, FOLLOW SAME PROCEDURE FOR SQUARE FRAME.

FIXTURE INSTALLATION



-
1. ATTACH THE MOUNTING DISC TO THE CEILING USING THE PERFORATIONS AND APPROPRIATE HARDWARE FOR THE MATERIAL OF THE CEILING. MAKE SURE THE RED AND BLACK WIRES FROM THE DRIVER ARE ACCESSIBLE. (FIGURE 1)
 2. CONNECT THE RED AND BLACK WIRES FROM THE DRIVER TO THE RED AND BLACK WIRES ON THE BONGO. (FIGURE 2)
 3. ATTACH THE BONGO TO THE CEILING BY SCREWING IN THE FIXTURE ONTO THE MOUNTING DISC. IF THE BONGO IS ORIENTABLE, ORIENT IT TO THE DESIRED LOCATION AND TURN THE FIXTURE ON. (FIGURE 3)